



### IT1 Boiler Room Thermostat

Brushed Stainless Steel

Low voltage circuit.

Mounts outside the steam room using standard single switch electrical box. (May be mounted directly on boiler using provided knock outs.)

Thermostat with off position, adjusts room temperature from approx. 90°F to 124°F.

Connects to boiler using three conductor signal wire such as thermostat/alarm cable.

LED lights to indicate steam room is in use.

The IT1 thermostat is used to set the steam bath temperature. The dial also has an integral switch so it may be used as a bath On/Off control.

When used with the I60, the thermostat should be left in the On position (so its Bath On indicator LED will light).

One IT1 is required for each room and only one may installed per room.